

BIOPAK 240 REVOLUTION



BioPak 240R

Closed-Circuit, Self-Contained Breathing Apparatus

User Instructions

CE 1437

Contents

WARNINGS	3
1. INTRODUCTION	4
1.1 Breathable Oxygen	4
1.2 Apparatus Duration	4
1.3 Personnel Training	4
1.4 Servicing	4
1.5 Spare Parts	5
2. APPARATUS DESCRIPTION	6
2.1 General	6
2.2 Harness	6
2.3 Housing	6
2.4 Breathing Loop	7
2.5 Oxygen Delivery System	7
2.6 Oxygen Cylinder	7
2.7 Alarming System	7
2.8 Facemask	8
2.9 Optional Attachments	8
3. PREPARATION FOR USE	10
3.1 Maintenance Tag Inspection	10
3.2 Mask Preparation	10
3.3 Moisture Sponge Preparation	10
3.4 PCM Installation	10
3.5 Carbon Dioxide Scrubber Installation	11
3.6 Coolant Canister Installation	12
4. DONNING THE APPARATUS	13
4.1 Donning the Apparatus	13
4.2 Donning the Facemask	13
4.3 Activate Oxygen Supply	14
5. PRACTICAL USE	15
5.1 Breathing the Apparatus	15
5.2 Speaking	15
5.3 Alarming System	15
5.4 Coolant Replacement	15
5.5 Emergency Bypass	15
5.6 Emergency Operation	15
6. DOFFING THE APPARATUS	16
6.1 Doffing Instructions	16
7. APPARATUS SPECIFICATIONS	17



WARNINGS



Please Read Carefully and Fully Understand

This manual is for use by personnel trained in the use and care of compressed oxygen, closed-circuit breathing apparatus, and **MUST NOT** be used as a self-teaching guide by untrained users. Failure to understand or adhere to the **BioPak** user instructions and **BioPak** benchman manual may result in injury or death.

Biomarine Inc. has taken great care to ensure that the information in the manual is accurate, complete and clear. However, **Training & Technical Support Services** will be pleased to clarify any points in the manual and answer questions on **Biomarine** breathing apparatus.

The following warnings are in accordance with certifying authority requirements and apply to the use of breathing apparatus in general:

- Breathing apparatus user must be fully trained in the use and care of closed-circuit, self-contained, compressed oxygen breathing apparatus.
- Ensure that the selection of the apparatus type is sufficient for the tasks being undertaken and the hazards likely to be encountered. Please refer to National Regulations for guidance.
- Adequate protection may not be provided in certain highly toxic atmospheres.
- The apparatus must be tested and serviced in accordance with the **BioPak 240R** Benchman Manual.
- The quality of oxygen used to supply and charge the breathing apparatus must be medical or aviation grade oxygen with a moisture content less than 50 mg/m³ at 207 bar.
- Ensure that a good seal can be obtained between the face and facemask. The wearing of beards, side-burns or spectacles may adversely affect the sealing of a facemask to the wearer's face.
- The apparatus is not designed for use underwater diving.
- The harness must not be used as a vehicle seat or fall arrest restraint.
- Replacement of the alarm system battery shall be performed in area atmospheres known to be safe and non-explosive.
- The improper use of closed-circuit breathing apparatus carries a risk of carbon dioxide poisoning of user. Users shall be fully trained in recognizing the effects of carbon dioxide poisoning.
- Carbon Dioxide Scrubbers must be stored at a temperature between 4°C and 32°C to prevent degradation of the absorbent material.
- Carbon Dioxide Scrubbers must be utilized with the supplied Moisture Pad to prevent scrubber canister flooding that may lead to elevated carbon dioxide levels in the breathing gas.

DISCLAIMER

Failure to comply with these instructions or misuse of the apparatus may result in: death, injury or material damage, and invalidate any warranty or insurance claims.

This manual presents the minimum requirements for **BioPak** utilization.

1. INTRODUCTION

1.1 Breathable Oxygen

Oxygen used to supply or charge the breathing apparatus must be medical or aviation grade oxygen with moisture content less than 50 mg/m³ at 207 bar. The composition of suitable oxygen is given below and provides the maximum level of contaminants in the source oxygen acceptable for use in the BioPak.

Oxygen: 99.5% minimum mole
Carbon Dioxide: 300 ppm maximum
Carbon Monoxide: 10 ppm maximum

The purity/quality of oxygen used to supply and charge breathing apparatus should be tested periodically in accordance with national regulations.

National regulations must be observed.

Personnel dealing with compressed oxygen and compressed oxygen cylinders must be fully trained in the use and handling of compressed oxygen.

1.2 Apparatus Duration

The apparatus will provide the user with 440 liters of compressed oxygen and has been rated for a 4-hour duration based upon machine testing at a breathing rate of 30 liters/minute according to specifications of EN145. Actual duration of the apparatus will vary to factors such as:

- **Workload:** high work rates will increase consumption rates of oxygen.
- **Facemask Seal:** poor seal of mask will result in system leaks and high oxygen consumption rates.
- **Physical Fitness of Wearer**
- **System Leaks:** leaks in the BioPak system will result in high oxygen consumption.

It is important that all wearers are aware of the above factors and take account of them when assessing BioPak duration.

It is equally important that all wearers understand that the BioPak 240R respirator is a positive-pressure apparatus. Leaks in the apparatus itself or in the seal between the wearer's face and the facemask will lead to the apparatus adding additional oxygen to maintain positive pressure.

1.3 Personnel Training

Personnel who use closed-circuit, self-contained, positive-pressure, compressed oxygen breathing apparatus must be fully trained in accordance with these instructions and national regulations.

These instructions cannot replace an accredited training course provided by qualified instructors in the proper and safe use of **Biomarine** breathing apparatus.

Please contact **Training & Technical Support Services** or your local distributor for training course details.

1.4 Servicing

The BioPak 240R must be serviced at scheduled intervals by qualified benchmen personnel who have completed a formal training course and hold a current certificate for the service and repair of **Biomarine** breathing apparatus.

Turn Around Maintenance shall be performed after each use of the BioPak 240R as detailed in the **BioPak 240R Benchman Manual**.

Long Term Maintenance must be performed on a monthly basis, if the BioPak is in constant use; or, on a quarterly basis if the BioPak is being used less than once per month, as defined in the **BioPak 240R Benchman Manual**.

Electronics Intrinsic Safety Assessment Procedure must be performed each time the batteries are replaced in the alarming system as defined in the **BioPak 240R Benchman Manual**.

Benchman training and service contracts can be provided by contacting **Training & Technical Support Services**.

1.5 Spare Parts

Spare parts, accessories, general information and factory service can be obtained by contacting **Training & Technical Support Services**.

Reference details provided in the **BioPak 240R Benchman Manual** concerning spare part identification, accessory identification and BioPak factory service.

Training & Technical Support Services:

Biomarine Inc.
A Wholly Owned Subsidiary of
Neutronics Inc.

456 Creamery Way
Exton, PA 19341
United States of America

Tel: +1 610.524.8800

Fax: +1 610.524.8807

Web: BioPak240r.com

Customers can also contact their **local authorized Biomarine Distributor** for training, product support, service or maintenance.

Reference documentation supplied with sales order for standard terms of warranty.

2. APPARATUS DESCRIPTION

2.1 General

BioPak 240R is a closed-circuit, positive-pressure, self-contained breathing apparatus (CCBA) for use in long-duration missions into atmospheres that are immediately dangerous to life and health (IDLH). Applications will include mine rescue, fire-fighting, confined space entry, domestic preparedness, military, tunnel rescue and HAZMAT.

All versions of the **BioPak 240R** feature a backpack-style housing that is worn over the shoulders and hips of the wearer. A pressure gauge is supplied to indicate remaining stores of oxygen and two visual alarms and one audible alarm is provided for system status.

The closed-circuit design will recycle the wear's exhalation breath by removing carbon dioxide, replacing consumed oxygen, trapping condensation and cooling the breathing gas.

The positive-pressure design will maintain internal breathing gas pressures slightly above external atmospheric pressure. This feature will provide increased protection against the inward migration of external toxins to the wearer.

All external housing components are static dissipative and flame retardant.

BioPak 240R is approved to the following European Standards:

- EN 136:1998 Respiratory protective devices - Full face masks
- EN 145:2000 Respiratory protective devices – Self-contained, closed-circuit breathing apparatus compressed oxygen type
- Directive 97/23/EC Pressure Equipment Directive
- EN 60079-0:2009/08/01 Electrical apparatus for explosive gas part 0: General Requirements
- EN 60079-11:2007/01/01 Explosive Atmospheres-Part 11: Equipment protection by intrinsic safety "I"
- EN 60079-26:2007/03/01 Explosive Atmospheres-Part 26:

Equipment with protection level (EPL) GA

- IEC 60079-0:2007/10/01 Ed:5 Explosive Atmospheres-Part 0:equipment-General Requirements
- IEC 60079-11:2006/07/01 Ed:5 Explosive Atmospheres-Part 11: Equipment protection by intrinsic safety "I"; CORR 2006/12/08
- EN 60079-26:2006/08/01 Ed:2 Explosive Atmospheres-Part 26; Equipment with protection level (EPL) GA

BioPak 240R is "CE" marked in accordance with EEC Directive 89/686/EEC.

BioPak 240R Monitor is marked Ex ia I/IIC T4 Ma/Ga
 $-20^{\circ}\text{C} <+ T_{\text{amb}} <+ 60^{\circ}\text{C}$

NOTIFIED BODIES:

Central Institute for Labour Protection
(Notified Body No. 1437)
Wierzbowa 48
90-133 Lodz, Poland

Intertek Testing & Certification Ltd
Intertek House, Cleeve Road
Leatherhead, Surrey KT22 7SB
United Kingdom

TUV America, Inc.
Industry Service
5 Cherry Hill Drive
Danvers, MA 01923
United States of America

Please contact **Biomarine Inc** for further apparatus approval details.

2.2 Harness

The **BioPak** harness is provided as a padded harness to increase wearer comfort. The flame-retardant harness is manufactured from Kevlar™ and Nomex™ materials with stainless steel hardware. The harness is attached directly to the apparatus via locking stainless steel screws.

2.3 Housing

The backpack-style housing is injection molded from a flame-retardant polycarbonate/stainless steel alloy that provides light weight, high strength and static dissipation. The housing consists of a lower portion and an upper portion that

snaps together in a secure fashion without the need for connection hardware.

2.4 Breathing Loop



The breathing loop consists of the breathing chamber, breathing hoses, facemask connector and facemask.

The breathing chamber consists of the center section, center section lid and diaphragm. The spring loaded diaphragm will maintain positive pressure within the apparatus. All oxygen gas additions will occur within the breathing chamber as well as over pressure venting. Carbon dioxide is removed from exhalation gas by the carbon dioxide scrubbers located within the breathing chamber. Excessive moisture will be retained by the moisture containment sponges located within the center section. Inhalation breathing gas cooling will be achieved as the gas travels around the two coolant canisters of the breathing chamber.

2.5 Oxygen Delivery System

Oxygen will be delivered from the oxygen cylinder to the breathing loop through a pressure regulator and manifold system in one of three different methods.

Pressure demand oxygen additions are provided whenever the diaphragm of the breathing chamber reaches the upper level of its travel and depresses the demand valve plunger. Additions will be made at 80 liters/minutes whenever the demand valve plunger is depressed. Pressure demand additions occur whenever the wearer consumes more oxygen than is supplied by the constant add.

Constant add oxygen additions are continually added to the breathing loop at an average rate of 1.8 liters/minute. This oxygen addition rate is equivalent to the oxygen consumption rate of a wearer at a moderate work rate.

Emergency add oxygen additions occur whenever the wearer depresses and holds the red emergency bypass button. This

add will provide 80-100 liters/minute of oxygen flow and is utilized only for emergency situations.

2.6 Oxygen Cylinder

The oxygen cylinder is a fully wrapped aluminum carbon fibre composite cylinder that is secured into the apparatus via connection to the pressure regulator and a hold down strap. The cylinder will provide containment of the oxygen supply at a 207 bar to provide 440 liters of breathable oxygen to the wearer.

2.7 Alarming System

The alarming system consists of a pneumatic pressure gauge and an electronic monitor to provide the wearer with independent and redundant system status indications.



The pressure gauge is mounted on the harness and retained by a snap strap and magnet. Remaining stores of oxygen will be indicated on the gauge and a red band of color will indicate to the wearer when oxygen stores have reached 25% of capacity. The pressure gauge is protected against sudden loss of oxygen stores in the event of gauge line severing by a manual disconnect located at the gauge pass through point of the housing.

The electronic monitor will provide the wearer of indications of system status as listed below through the LED located on the pneumatic pressure gauge and via an alarm horn located on the monitor package.

<u>Condition</u>	<u>Alarm Action</u>
System Ok	Flashing Green
System Fault	Flashing Red Horn Sounding
End of Service Life	Flashing Red Horn Sounding
Ice Reminder	Flashing Blue
Low Battery	Flash Red , Green , Blue Horn Sounding

2.8 Facemasks

BioPak 240R is approved for use with the **PRO** and **AV3000** full facemasks, all of which conform to EN136, Class 3.

All facemasks are provided with five-point, fully adjustable head harnesses.

To prevent fogging during use, the internal surface of the facemask lens is covered with a permanent anti-fog film that will not require the application of any anti-fog spray or wipe.

All facemasks connect to the apparatus via a push button, bayonet hose connection.

Speech diaphragms are provided to allow verbal communication and all masks are provided with a magnetic wiper the is for optional user utilization.

The polycarbonate visors of all facemasks conform to EN 166, Grade B for impact resistance.



PRO Mask



AV3000 Mask

2.9 Optional Attachments

- Hydration systems provide the wearer with a source of drinking liquid without breaking the seal of the breathing loop to the external atmosphere.
- Anti-crush rings provide breathing hose crushing and restriction protection.
- Kevlar™ breathing hose covers provide additional abrasion protection to breathing hoses.
- Radiant heat guards provide additional breathing hose protection against high radiant heat and direct flame contact.



- Phase Change Module (PCM) provides cooling to the breathing gas when ice coolant is not utilized. Note that the PCM is **required** when the ice coolant is not utilized.

Contact **Biomarine** or your local distributor for additional details and supply of optional attachments.



3. PREPARATION FOR USE

Prior to donning the apparatus the wearer shall conduct the following procedures to ready the apparatus for use.

3.1 Maintenance Tag Inspection

C47D138, REV. B
[09/2013]



**BIOPAK 240 REVOLUTION
TURNAROUND MAINTENANCE TAG**

UNIT NO: 0031246

	DATE	INT.
WASHED/DISINFECTED	6/24/13	WRF
O2 CYLINDER REPLACED/FILLED	6/24/13	WRF
FLOW TEST <u>1.8</u> lpm	6/24/13	WRF
CO2 CARTRIDGES REPLACED	6/24/13	WRF

SERIAL #: R2013-728-1122544

EXPIRATION DATE: JUNE/2014

MASK INSPECTION	6/24/13	WRF
ICE PLACED IN FREEZER	6/24/13	WRF
LOW PRESSURE LEAK TEST	6/24/13	WRF



WARNING

- * INSTALL FROZEN ICE PRIOR TO USE.
- * REFER TO USER MANUAL AND/OR MAINTENANCE MANUAL FOR INFORMATION ON USE AND MAINTENANCE OF THIS RESPIRATOR.
- * RESPIRATOR IS SUITABLE FOR USE ONLY BY PROPERLY TRAINED PERSONNEL.
- * FAILURE TO PROPERLY USE AND MAINTAIN THIS RESPIRATOR COULD RESULT IN INJURY AND DEATH.


Locate and inspect the maintenance tag that should be attached to the apparatus. Verify that all items on the tag are properly dated and initialed. **If the maintenance tag is missing or not properly completed the apparatus MUST NOT be placed into service until full turn around maintenance has been completed as specified in the BioPak 240R Benchman Manual.**

3.2 Mask Preparation

Do not apply anti-fog agents of any kind to the facemask. The facemask is supplied with a permanent anti-fog film that will prevent fogging.

If the optional magnetic wiper is used, soak both chamois surfaces of the wiper pieces with anti-fog or water and install onto the lens of the facemask so that the chamois side of each piece is in direct contact with the lens. The wiper is to be installed with the thinnest section positioned on the inside surface of the mask.

3.3 Moisture Sponge Preparation



Remove the moisture sponges from the breathing chamber and wet until supple. Wring out excess water and replace into the breathing chamber. If the sponges are not pre-wetted prior to use the breathing air to the wearer will be warmer than usual.

Note: Pre-wetting of the sponges is **OPTIONAL** but will provide cooler initial breathing gas temperatures.

3.4 PCM Installation

If the ice canisters are not utilized that install the PCM canister into the center section as depicted below.




3.5 Carbon Dioxide Scrubber Installation

Note: The scrubbers may have already been installed by the BioPak technician prior to use. In such cases the user should verify the scrubber expiration date has not been exceeded by inspecting the date recorded on the maintenance tag.



Inspect the expiration date of the carbon dioxide scrubber to ensure that it is not expired. Record the serial number and expiration date of the scrubber onto the maintenance tag or affix the scrubber label to the rear of the tag.



Verify that each scrubber housing contains an o-ring seal and install each into the breathing chamber making sure that each scrubber is fully seated and properly aligned as depicted above. Position the canisters so that the top indicator arrow is pointing at the center of the breathing chamber.



Remove the moisture pad, depicted above in sealed bag, from the sealed pouch and install it into the breathing chamber as depicted. Do not allow the pad to become pinched between the breathing chamber wall and the scrubber. The pad shall be located right next to the baffle opening that leads to the coolant canisters.



Proper moisture pad installation.

WARNING: Failure to install the moisture pad can lead to scrubber flooding that will result in elevated carbon dioxide levels in the breathing gas that may lead to injury or death.

3.6 Coolant Canister Installation

Remove the coolant lids from the center section lid and insert a fully frozen ice canister into each location. Replace the coolant lids.



Coolant canisters are to provide wearer comfort but are not required for certified operation of the **BioPak**.

Recommended Safe Duration with Respect to Ambient Temperatures

The apparatus should be utilized with the coolant canisters installed for high ambient temperatures. Recommended apparatus duration of use with the coolant canisters installed:

<u>Ambient Temperature</u>	<u>Recommended Safe Duration</u>
41 to 60°C	1-hour
61 to 90°C	15-minutes
+90°C	6-minutes

4. DONNING THE APPARATUS

4.1 Donning the Apparatus

Specialist Users (such as Emergency Services) may operate alternative donning procedures that conform to the relevant statutory regulations.

1. Check that the shoulder and waist harness straps are fully slackened.
2. Pass right arm through the shoulder strap and repeat for the left arm.



3. Bend over and pull down on the two shoulder strap adjustments to position the apparatus on the shoulders.



4. Connect the waist belt straps together and pull the adjust straps forward to snug the apparatus to the hips.
5. Connect and adjust the harness chest strap.



6. Position and secure the pressure gauge to the magnet of the shoulder strap and secure with the snap strap. An alternative magnetic location is positioned on the waist belt.



7. Flip the breathing hoses over the shoulders and secure hose to the harness using the hose straps.

Position of the hose straps can be adjusted for optimal head movement.

The apparatus can be adjusted to rest either on the hips or shoulders of the wearer by adjustment of the shoulder straps.

4.2 Donning the Facemask

1. Check that the head harness straps are fully slackened.



2. Hold the head-harness lower straps, place chin in chin-cup and pull straps over back of head, brushing hair away from face seal.



3. Adjust the facemask top strap so that the mask is at the correct level with the face and the head-harness pad is in the center of the back of the head, then tighten harness straps in sequence, **Bottom, Middle, Top**. DO NOT over-tighten.



4. Depress the push button of the facemask front port and insert the breathing hose adapter into the port. Release the push button and tug and the breathing hose adapter to ensure that it securely anchored.

4.3 Activate Oxygen Supply



1. Reach back and turn the green oxygen knob located on the right side of the apparatus house to its full counterclockwise position.
2. Inspect the pressure gauge and LED. The pressure gauge shall read a minimum of 200 bar pressure to achieve full apparatus duration. The TRIM monitor shall initially flash **RED**, **GREEN**, **BLUE** with the horn sounding. The LED shall then flash **GREEN** to signal acceptable system status. If after 5-10 minutes of operation if the LED flashes **BLUE**, this is an indication to check that the coolant canisters have been installed. This is a self-cancelling alarm that will return the LED to flashing **GREEN** after 5-minutes.

DO NOT take the apparatus into service if the pressure gauge or TRIM indicator is not functioning as described above or if the TRIM indicator is flashing **RED**.



3. With two hands collapse the **inhalation** hose and inhale. Proper sealing of the **exhalation check valve** will result in the facemask being pulled in toward the face.



4. With two hands collapse the **exhalation** hose and exhale. Proper

sealing of the **inhalation check valve** will result in the facemask being pushed away from the face.

DO NOT take the apparatus into service if the check valves do not pass the tests of steps 3 and 4.



5. Depress the red emergency bypass for 1-2 seconds and release. Verify the sound of oxygen gas additions into the breathing chamber while the button is depressed and that the oxygen additions cease when the button is released.

DO NOT take the apparatus into service if the emergency bypass valve does not pass the above test.

5. PRACTICAL USE

5.1 Breathing the Apparatus

There is no need to accelerate or deepen normal breathing rates. The apparatus will automatically adjust oxygen additions to match the needs of the user.

5.2 Speaking

The facemask is provided with a speaking diaphragm that will transmit sound from the interior of the facemask to the external surrounding environment. Speak slightly louder and slower than normal making every effort to clearly pronounce words. Do not shout.

Optional voice amplification devices can be attached to the facemask prior to donning to enhance clarity of speech. Contact **Biomarine** or your local distributor for details and supply.

5.3 Alarming System

The wearer should frequently inspect the pressure gauge and LED throughout the duration of the mission.

Should the pressure gauge indicate pressure in the **RED** colored area of the gauge, the end of service life of the apparatus is near and the wearer shall retire to a safe location as quickly as possible to doff the apparatus.

Should the LED flash **RED** and/or the horn sounds, the wearer shall retire to a safe location as quickly as possible to doff the apparatus.

5.4 Coolant Replacement

If the breathing air becomes uncomfortable to the wearer the coolant canisters can be replaced without doffing the apparatus or breaking into the breathing loop.

Replacement of the ice canisters while wearing the apparatus will require assistance.

1. Remove the coolant covers from the breathing chamber lid.
2. Remove the spent coolant canisters from the breathing chamber lid.
3. Install replacement, fully frozen, coolant canisters into the breathing chamber lid.
4. Replace the coolant lids to the breathing chamber lid.

5.5 Emergency Bypass



The emergency bypass is for emergency use only.

DO NOT attempt to use the emergency bypass to cool the breathing gas or clear the facemask of fogging.

Depress in 1-2 second periods for optimal use.

Continued use of the emergency bypass will shorten apparatus duration.

5.6 Emergency Operation

Follow the procedures below in event of the described emergency situation.

Equipment Failure

Should any component of the apparatus experience a failure or should the apparatus upper housing become dislodged, the wearer shall immediately retire to safe location to doff the apparatus.

Gauge Line Severing



Should the gauge line feeding the pressure gauge become severed the apparatus will begin to leak oxygen. To stop the loss of oxygen reach back and pull up on the quick disconnect fitting to release the gauge line and seal the leak. The wearer shall immediately retire to a safe location and doff the apparatus.

6. DOFFING THE APPARATUS

6.1 Doffing Instructions

1. Retire to a known safe location and doff the apparatus.

DO NOT remove the apparatus until well clear of the hazardous area.

To prevent the growth of germs, bacteria and mold, conduct turn around maintenance on the apparatus as quickly as possible.

7. APPARATUS SPECIFICATIONS

Respirator Type:	Self-Contained, Closed-Circuit, Pressure-Demand
Respirator Duration:	Certified as entry and escape, 4-hour duration
Size:	584 x 439 x 178 mm
Weight (Fully Charged):	15.4 kg Maximum
Operational Conditions ¹ :	Temperature: -5°C to 40°C Air Pressure: 900 to 1200 hPa Relative Humidity: 0 to 100%
Storage Conditions:	Temperature: 4°C to 32°C Air Pressure: 900 to 1200 hPa Relative Humidity: 30 to 100%
Oxygen Delivery:	Constant Add: 1.8 lpm Average Demand Add: 80 lpm Minimum Emergency Add: 80 lpm Minimum
Oxygen Supply:	> 99.5% Oxygen by volume < 300 ppm Carbon Dioxide < 10 ppm Carbon Monoxide 50 mg/m ³ Water Content Maximum Tasteless and Odorless 440 liter storage at 207 bar pressure
Battery:	Power: 9 Vdc Life: 200-hours or six months Type: Only the below types may be used Energizer 522 Panasonic 6AM6 Rayovac A1604 Duracell MN1604
Carbon Dioxide Scrubber:	Dual, single use "Solid-Core" canisters Non-dusting Non-settling Non-channeling
Tidal Volume:	6.0 liters

Note:

1. Operating temperature range provided above is the standard 4-hour duration with PCM installed. For extreme temperature ranges, the BioPak should be configured with ice coolers and utilized as directed below:

<u>Ambient Temperature</u>	<u>Recommended Safe Duration of Use</u>
41 to 60°C	1-hour
61 to 90°C	15-minutes
+90°C	6-minutes

The above temperature/duration figures are derived from human endurance limits and not from the endurance limit of the BioPak.

(This page left intentionally blank)